

Coat hook

12mm +



Includes universal fixings		
Panel thickness	ANODISED	PPC
12mm +	N/A	HOOK03P-7024M

1. Position the coat hook and using the fixing holes as a guide mark the door.
2. Remove the coat hook and predrill the door. Being careful not to go all the way through.
3. Re position the coat hook and fix in place with the correct fixings.
4. Check the coat hook is secured properly.

