

Toilet Roll Holder T01 & T02

12mm +



Includes universal fixings

Panel thickness	ANODISED	PPC
12mm +	T01A1221	T02P1221
12mm +	T02A1221	T02P1221

1. Position the Toilet Roll Holder and using the fixing holes as a guide mark the panel.
2. Remove the Toilet Roll Holder and predrill the panel. Being careful not to go all the way through.
3. Re position the Toilet Roll Holder and fix in place with the correct fixings.
4. Check the Toilet Roll Holder is secured properly.
5. (T01 only) Insert the sprung loaded tube.
6. (T02 only) Insert the heavy duty tube and secure in place with the M6 screws provided.

No.8 x 1/2" CSK SCREW (12-13mm)

No.8 x 5/8" CSK SCREW (17mm +)

